


# WOODEN PLYO BOX - ASSEMBLY DRAWING



# 3-in-1 Plyobox Instructions

The wooden plyometric box offers three sizes of plyo box for the price of one. Three sided box designed for using in the crossfit gym club.

This plyometric box is solid on all 6 sides and is 20" x 24" x 30". This plyometric box is extremely sturdy on each side and the surface of box is sanded completely to avoid any sharp edges. Each box is sprayed with two coats of poly to protect the exterior wood.

Notes:

1. Pocket screws and fasteners.

2. It is made of durable material and in the box there are wooden support to make it more stronger.

3. Ships unassembled. so that it is small packaging cubic and can reduce your shipping cost.

Please assemble the box according to the finger to the same finger (for example 1-1)

4. Do Not slam the wooden plyometric boxes.

5. Do Not use the plyometric boxes on the rough floor.

6. Hardware can not be assembled and unassembled more than three times, because that will make the screws loose.

If buyers do not use the plyo box in a correct way to cause a series of problems, sellers will not take responsibility for that.